



Sheardy's
A-1 Rental & Concrete
1251 W. Caro Rd (M-81)
Caro, MI 48723

Common Sense Solutions

www.a1rentalonline.com

POPCORN MACHINE

989 673 - 6138

OPERATING MACHINE:

- Plug in machine.
 - Flip the kettle lid up to open.
 - Turn **HEAT** and **LIGHT** switch to **ON** (Waite 3-4 minutes for kettle to heat up.)
- When ready to add oil qand popcorn, turn **KETTLE MOTOR** switch ON to start the motor.
- Open the oil pouch and pour into the kettle.
 - Immediately add the popcorn. (**DO NOT OVERFILL:** only pop one popcorn pack at a time.)
 - Pull the kettle likd downward for the top of the cabinet to cover the kettle.

DO NOT FORGET TO COVER THE KETTLE OR THE OIL AND POPCORN WILL IMMEDIATELY SPRAY OUT ALL OVER THE SIDES OKF THE MACHINE.

- While the corn is popping kopern the plexi-glass doors slightly to prevent fogging.
- Popcorn will pop quickly, and when the popping ceases, **TURN BOTH THE KETTLE HEAT AND MOTOR SWITCH OFF.**
- Lift the kettle lid until it attaches to the magnet on top of machine. Dump popped corn by releasing the kettle, rotating the black handle to hook the kettle to the holding bolt. **USE CAUTION - THE KETTLE IS VERY HOT !!!!!**
- Repeat steps 2-12 for additional batches. Each dual pack of popcorn and oil makes 10 2-cup servings.
- If you are making several batches continuously you do not have to wait for machine to reheat, it will already be pre-heated.
- Remember to turn **HEATING LIGHT SWITCH** to **ON** in order to keep your popcorn warm.

CLEANING MACHINE:

- Popcorn machine must be returned clean. There is a **\$ 25.00 CLEANING CHARGE** for machines that have not been cleaned.
- Wait at least one hour ukntil the kettle has completely cooled. The kiettle can be very hot - **USE CAUTION.**
- Wipe all oil off the inside and outside of the kettle with a **DRY** clean soft cloth. **NEVER PUT WATER ON THE KETTLE !!!!!**

Work or Play

A-1 is the Way